

Description

Type A maintenance – every 10 000 km:

- check the level of oil, coolant, windshield wiper fluid
- diagnostics of the general condition of the car: electricity, steering system, brake system, air conditioning system
- oil change in the combustion engine
- diagnostics of a running gear
- greasing of a cardan shaft
- replacement of the oil filter
- replacement of cabin filter
- replacement of the air filter
- replacement of the fuel filter
- wheel alignment

Type B maintenance – every 30 000 km:

- check the level of oil, coolant, brake fluid, windshield wiper fluid
- diagnostics of the general condition of the car: electricity, steering system, brake system, air conditioning system
- check of oil level in a transmission (to top up if necessary)
- oil change in the combustion engine
- diagnostics of a running gear
- greasing of a cardan shaft
- replacement of the oil filter
- replacement of the cabin filter
- replacement of the air filter
- replacement of the fuel filter
- wheel alignment

Type C maintenance – every 60 000 km:

- check the level of oil, coolant, brake fluid, windshield wiper fluid
- diagnostics of the general condition of the car: electricity, steering system, brake system, air conditioning system
- check of oil level in a transmission (to top up if necessary)
- oil change in the combustion engine
- diagnostics of a running gear
- greasing of a cardan shaft
- replacement of the oil filter
- replacement of the cabin filter
- replacement of the air filter
- replacement of the fuel filter
- wheel alignment
- oil change in the junction box
- oil change in axles (front and rear)
- replacement of brake fluid

Type D maintenance – every 90 000 km:

- check the level of oil, coolant, brake fluid, windshield wiper fluid
- diagnostics of the general condition of the car: electricity, steering system, brake system, air conditioning system



- check of a drive belt of hinged units and a set of rollers
- oil change in the combustion engine
- diagnostics of a running gear
- greasing of a cardan shaft
- replacement of the cabin filter
- replacement of the oil filter
- replacement of the air filter
- replacement of the fuel filter
- wheel alignment
- oil change in the junction box
- oil change in axles (front and rear)
- replacement of radiator coolant
- replacement of brake fluid
- change of oil in a transmission